

Caution in use

- With link clamps, force acting on link mechanism becomes larger as clamp arm becomes shorter. Exceeding maximum allowable load for link mechanism will lead to malfunction. Depending on clamp arm length, it would be necessary to lower clamping force (hydraulic pressure). Use a clamp at appropriate clamping force that is suitable for clamp arm length, referring to performance diagram and table.
- Determine height and mount clamp, ensuring that clamp arm becomes parallel to clamping surface and mounting surface when workpiece is clamped (allowable angle $\pm 3^\circ$).
- Using a method such as that shown in the diagram on the right will apply a transverse force on the piston rod and cause the piston rod to break. Please avoid the usage that may apply a non-axial force to the piston rod.

